


A . Features

- 12 Digits LCD Display , Display Hour , Minute , Second , Month , Date and Day of Week
- Daily Alarm and Chime hourly
- Snooze
- 12 / 24H format selectable
- 1/100 second Chronograph with split functions
- EL backlight

B . Operational Manual



1. At any state , press **A** key EL backlight for 3s .

2. Chronograph

- At the Chronograph mode , Press **D** key to Start/Stop running ;
- When stop , press **C** key to zero .
- When running , press **C** key to split count. indicator "SP" showing
- Then press **D** key to exit split count , and stop counting ; press **C** key again to zero;
- When finish , press **B** key to return to Real Time Mode .

3. Daily Alarm

- At the Alarm mode , Turn On / Off Alarm and Chime
Press **D** key to turn on/off Alarm (**AL**) or Chime (**CH**)
- Alarm setting : Press **C** key to select "Hour " or "Minute "setting, Press **D** key to adjust the flashing item, Press **C** key to confirm, Press **B** key to return to Real Time mode.
- Alarm Snooze ON/OFF

At Alarm sounding state , press **C** key or **D** key to stop sounding ,and press **B** key to ON/OFF snooze function .When Snooze function be ON , it will sound five minutes later , and auto stop after sounding for 20 Second.

4. Time Setting

- At the Time setting mode , "Second " is flashing while loading , press **D** key to zero ; Press **C** key to select items as below sequence :
Hour → Minute → Month → Date → Day of Week
- Press **D** key to adjust the flashing item .
- When the setting is finished , press **B** key to return to the Real Time running .
- When setting " Hour " item ,12H or 24H format can be selected ; Displaying "A " or "P " is for 12H format and " H " for 24H format .

HOW TO SET THE ANALOG

If there is a plastic piece under the crown, gently remove it, press the crown down to normal position. Refer to the diagram below, gently pull the crown out to the first click position, The second hand will stop when the crown is in the first click position. When in the first click position, turning the crown will change the minute and hour hands. Set the correct time, then gently push the crown back to normal position, and the second hand will begin moving again indicating normal operation.

